

**WATKINS
MEDIA UNIT
TV ÜNİTESİ**

**SO.
MASS**

Placement and Maintenance

Your Watkins Media Unit is designed for indoor use on level floors. Furniture with hard lacquer, wax polish or painted surface should be dusted with a dry cloth. Spills should be wiped up immediately. Our furniture will endure most temperatures in the home but it is best to avoid placing furniture next to heat sources such as radiators or fires. For your questions and problems, send an e-mail to info@so-mass.com

Yerleşirme ve Bakım


Watkins TV Üniteniz iç mekanda düz zeminlerde kullanıma uygun olarak tasarlanmıştır. Sert cilalı, cilalı veya boyalı yüzeyli mobilyaların tozu kuru bir bezle silinmelidir. Döküntüler mümkün olan en kısa sürede silinmelidir. Mobilyalarımız evdeki çoğu sıcaklığa dayanıklıdır ancak mobilyaları radyatör veya ateş gibi ısı kaynaklarının yanına yerleştirmekten kaçınmak en iyisidir. Soru ve sorunlarınız için lütfen info@so-mass.com mail adresimizle iletişime geçiniz.

Step 1

Unpack and identify the parts listed below. **Two people are required to carry and assemble units weighing over 22 kg.** The assembly workspace should be a non-marring **surface such as carpet.**

Adım 1

Aşağıda listelenen parçaları ambalajından çıkarın ve tanımlayın. **22 kg'nin üzerindeki üniteleri taşımak ve monte etmek için 2 kişinin olması gerekir.** Montaj çalışma alanı halı gibi bozulmayan bir yüzey olmalıdır.



**C1 Watkins Media Unit x 1
C1 Watkins TV Ünitesi x 1**

